

Ethernet Digital I/O with Serial

EDIO-232

User Manual



Third Edition, Sep. 2010

Table of Contents

1. Introduction	3
Overview	4
Package Checklist	4
Block Diagram	5
Features	6
Product Specifications	7
2. Ethernet Digital I/O with Serial Description	9
Product Panel Views	9
Top Side	9
Front Side	9
Rear Side	10
Rear Side	10
LED Indicators	11
Wiring Architecture	12
RS-232	12
RS-422/RS-485	12
3. Ethernet Digital I/O with Serial Installation	13
Power Supply	13
Ethernet Port	13
Serial Port	14
RS-485/RS-422 Port	14
Dip Switch	14
Reset	14

4. Ethernet Digital I/O with Serial Configuration ...	16
Initial IP Configuration	16
Device Management Utility of CVBrowser.....	16
Menu “View”	18
Menu “Config”	18
Web Console Configuration	20
Controller Status	21
Controller Setup	24
Controller Updated	30
Factory Default Setting	31
5. Setting Verification	32
Hyper Terminal for TCP/IP WinSock	33
Hyper Terminal for COM Port	38
Data Transmission	39
Appendix A - FAQ	40
Appendix B - Pin Outs and Cable Wiring	41
B.1 DC-In Jack	41
B.2 RJ-45 Pin Assignment	41
B.3 RS-232 Pin Assignment	41
B.4 RS-232 Wiring Diagram	42
B.5 RS-422 Pin Assignment	42
B.6 RS-422 Wiring Diagram	42
B.7 RS-485 Wiring Diagram	42

1

Introduction

We provide new ways of connecting legacy serial devices to a Local Area Network (LAN) or Wide Area Network (WAN). Ethernet Digital I/O with Serial converters is designed to operate serial ports over 100M bps Ethernet networks and control Digital I/O via Ethernet. The data is transmitted via TCP/IP protocol. Therefore, control is available via Ethernet, Intranet and Internet. EDIO-232 converter is packaged in a Metal material case well suited for industrial environments. It provides two serial ports one is a RS-232 and another is RS-232/422/485 (Auto-Detect). All serial ports operate in common industrial configuration. It also provides eight of Digital Input with photo couple protect and three of Digital Output with power Relay.

EDIO-232 converter is a low-cost, high performance design and easy to control Digital I/O via Ethernet. By carefully selecting high quality with competitive prices components in the world, the products made network connectivity possible with affordable cost for virtually all kinds of devices.

The following topics are covered in this chapter:

- ❑ **Overview**
- ❑ **Block Diagram**
- ❑ **Product Features**
- ❑ **Product Specifications**

Overview

Model EDIO-232 converter is designed to make your industrial serial devices Internet ready instantly and control your Digital I/O via Ethernet very easy.

We used ARM Cortex-M3 CPU for EDIO-232 converters, It makes them the ideal choice for connecting your RS-232 and RS-422 or RS-485 serial device—such as PLCs, meters, and sensors—to an IP-based Ethernet LAN, making it possible for your software to access serial devices and Digital I/O anywhere and anytime over a local LAN or the Internet.

EDIO-232 Series converters ensure the compatibility of network software that uses a standard network API (Winsock or BSD Sockets) by providing TCP Server Mode, TCP Client Mode, and UDP Mode. Model EDIO-232 provides socket connection for remote management. We Provide Virtual COM driver and software that works with COM port can be setuped to work over a TCP/IP network in no time. This excellent feature preserves your software investment and let you enjoy the benefit of networking your serial devices instantly.

EDIO-232 series converter supports manual configuration via the handy web browser console and many protocols including TCP, IP, UDP, HTTP, DHCP, ICMP, and ARP. They are the best solution to network your serial devices.


Package Checklist

EDIO-232 product is shipped with the following items:

- ❑ 1 unit of EDIO-232 converter
- ❑ 1 unit of Power Adaptor (12V DC, 1000mA)
- ❑ Quick Installation Guide in Documentation & Software CD

NOTE: Please notify your sales representative if any of the above items is missing or damaged.

Block Diagram



Low-cost devices usually are equipped with low speed processors and limited memories. In reality, they have neither the capability nor practicality to manage complicated network TCP/IP protocols. The ARM Cortex™-M3 32-bit processor has been specifically developed to provide a high-performance, low-cost platform for a broad range of applications including microcontrollers, automotive body systems, and industrial control systems, networking by converting data stream between network TCP/IP and popular serial port signals.

Instead of processing TCP/IP packets directly, devices need only deal with those interface signals, which greatly simplifies the complexity of TCP/IP network in linkage. The ARM Cortex-M3 processor provides outstanding computational performance and exceptional system response to interrupt while meeting low cost requirements through small core footprint, industry leading code density enabling smaller memories, reducing pin count, and low power consumption.

The central core of ARM Cortex-M3 processor, based on a 3-stage pipeline Harvard bus architecture, incorporates advanced features including single cycle multiply and hardware divide to deliver an outstanding efficiency of 1.25 DMIPS/MHz. The ARM Cortex-M3 processor also implements the new Thumb®-2 instruction set architecture, which combined with features such as unaligned data storage and atomic bit manipulation delivers 32-bit performance at a cost equivalent to modern 8- and 16-bit devices.

Product Features

- ❑ **Data Conversion between RS-232/422/485 and Ethernet**
EDIO-232 converter serial device (RS-232□1 port , RS-232/422/485□1 port) data/signal into the TCP/IP package data/signal and send them out with the Ethernet Data Stream; or convert the TCP/IP package data/signal into serial device data/signal.
- ❑ **Socket Communication**
EDIO-232 is provided one socket connection.
- ❑ **Digital I/O Activating (Optional)**
EDIO-232 provides eight of Digital Input and three of Digital Output.
Convert the sensors' statuses (the sensors are connected to the converter) into the TCP/IP package data and send them out with the Ethernet Data Stream; or use the TCP/IP package data to activate/deactivate the specified digital Input/Output.
- ❑ **Dynamic IP Configuration**
Support DHCP client mode, simplifying network address configuration and management.
- ❑ **Dual LAN Speed**
Support 10/100 Mbps Ethernet, auto-detected.
- ❑ **Server / Client Dual Modes**
EDIO-232 converter device can be configured as network server or network client. In the client mode, it can be installed in network which is protected by NAT router or firewall without a real IP address.
- ❑ **Web-based Setup**
Parameters setup is based on HTTP protocol by using standard browsers (IE and Netscape). No special software would be required.
- ❑ **Built-in Security Control**
Security protect by login password to prevent intruders.
- ❑ **Remote Update**
Firmware can be updated directly via COM Port to keep up with latest network standard.


Product Specifications

- CPU : ARM Cortex™-M3 32-bit processor , 50MHz
- RAM : 64K Bytes SRAM
- ROM : 256K Bytes Flash ROM
- Ethernet
 - Port Type : RJ-45 Connector
 - Speed : 10 /100 M bps (Auto Detect)
 - Protocol : ARP, IP, ICMP, UDP, TCP, HTTP, DHCP, ICMP
 - Mode : TCP Server/TCP Client/UDP Client / Virtual COM / Pairing
 - Setup : HTTP Browser Setup (IE & Netscape)
 - Security : Login Password
 - Protection : Built-in 1.5KV Magnetic Isolation
- Serial Port
 - No. of Ports : RS-232 □ 1 Port and RS-232/422/485(Auto-Detect) * 1 Port
 - Port Type □ DB9 male
 - Speed □ 300 bps □ 115.2K bps
 - Parity □ None, Odd, Even, Mark, Space
 - Data Bit □ 5, 6, 7, 8
 - Stop Bit □ 1 , 2
 - Port 1 □
 - One RS-232 Signals Port □ Rx , Tx , GND , RTS , CTS , DTR , DSR , DCD
 - Port 2 □
 - One RS-232/422/485 Port (Auto-Detect)
 - RS-232 Signals □ Rx, Tx, GND
 - RS-422 Signals □ Rx+ , Rx- , Tx+ , Tx- (Surge & Over Current Protect)
 - RS-485 Signals : Data+ , Data- (Surge & Over Current Protection)

- Built-in RS422/RS485 Pull High-Low Resistor
- Digital I/O Port
 - Digital Input * 8 pins
 - Digital Output * 3 pins
- Socket Port Connection □ 1 Connection
- 15KV ESD for all signal
- Watch Dog Function
- Virtual Support Windows 2000 /2003 / XP / Vista / Win-7
- Firmware On-line Updated Via COM portt
- Power □ DC 9 – 24 V , 1000mA
- LED Lamp □
 - SYS (Green- Blink)**
 - DI/DO (Red- Light When socket connect ,Blink during data transferring and receiving)**
 - Port-2 (Green- Light When socket connect , Blink during data transferring and receiving)**
 - Port-1 (Red- Light When socket connect , Blink during data transferring and receiving)**
- Environment □
 - Operating Temperature □ 0 □ □ 70 □
 - Storage Temperature □ -10 □ □ 80 □
- Dimensions □ 115 * 90 * 27 mm (W * D * H)
- WEIGHT □ 250 gm
- RoHS □ Compliant with RoHS
- Regulatory Approvals □ FCC, CE
- WARRANTY □ 1 year

Converter Description & Installation

Product Panel Views



Front View

Serial I/O Port of RS-232 and RS-232/422/485


Connect the serial data cable between the converter device and the serial devices. Follow the parameter setup procedures to configure the converter (see the following chapters).



Rear View

Digital I/O

Through EDIO-232 converter, Digital I/O can transform the status of sensor into the TCP/IP package data and send out by Ethernet Data Stream (The EDIO-232 converter must indicate the IP address and Socket Port) or activate the indicated Digital output (Remote WinSock must indicate the EDIO-232 converter).



Power Supply

EDIO-232 converter is powered by a single 12VDC (inner positive/outer negative) power supply and 1000mA of current. A suitable power supply adapter is part of the packaging. Connect the power line to the power jack at the left side of EDIO-232 converter device and put the adapter into the socket. If the power is properly supplied, the “SYS” red color LED will be Blink.


Ethernet LAN Port

The connector for network is the usual RJ45. Simply connect it to your network switch or Hub. When the connection is made, the LAN Green LED indicator will light up. When data traffic occurs on the network, Orange LED indicator will blink during data transferring and receiving.

Reset Button

If you forget the setup password or have incorrect settings which makes EDIO-232 converter inoperable. First, turn on the power. Second, use any point tip to push this button and hold it to turn on the power at the same time for 3 second. All the parameters will be reset to the factory default.

LED Indicators



SYS (Green):

It is a system operation indicator (When the system is on, the LED will blink).

DI / DO (Red):

It is the status of socket connection (LED light up when socket is connected, LED blinks during data transferring and receiving).

Port-2 (Green):

It is the status of socket connection (LED light up when socket is connected, LED blinks during data transferring and receiving).


Port-1 (Red):

It is the status of socket connection (LED light up when socket is connected, LED blinks during data transferring and receiving).

Wiring Architecture


RS-232 Wiring Architecture

RS-232 Wiring




E-P232-X-DIO	Serial Device
TX	RX
RX	TX
GND	GND

RS-232(RTS/CTS) Wiring



E-P232-X-DIO	Serial Device
TX	RX
RX	TX
GND	GND
CTS	RTS
RTS	CTS


RS-232(RTS/CTS , DTR/DSR) Wiring



E-P232-X-DIO	Serial Device
TX	RX
RX	TX
GND	GND
CTS	RTS
RTS	CTS
DSR	DTR
DTR	DSR


RS-422/RS-485 Wiring Architecture

RS-422 Wiring



E-P232-X-DIO	Serial Device
T-	R-
T+	R+
R-	T-
R+	T+

RS-485 Wiring



E-P232-X-DIO	Serial Device
D+	D+
D-	D-

When you finish the steps mentioned above and the LED indicators are as shown in above diagram, the converter is installed correctly. You can use the Setup Tool “CVBrowser.exe” to setup the IP Address.

To proceed the advanced parameter setup, please use a web browser (IE or Netscape) to continue the detailed settings.

Converter Configuration

Initial IP Configuration

When set up your converter for the first time, the first thing you should do is to configure the IP address. This chapter introduces the method to configure the device server's IP address. For more details about network settings, please see the Network Settings section in Chapter3, “Web Console Configuration”.

The following topics are covered in this chapter:

- ❑ **Device Management Utility**
- ❑ **CVBrowser “View”**
- ❑ **CVBrowser “Modify IP”**
- ❑ **CVBrowser “Modify MAC”**


Device Management Utility

On PC we provide a Device Management Utility named “**CVBrowser.exe**” which is an executable program in Windows 32-bit environments. CVBrowser setup tool is used to detect and setup the installed converters. It uses UDP broadcast packets to query and configure converters on the network.

When you activate the tool, it will detect the existence of the installed converters and depict the converters' status such as IP address, Subnet Mask, MAC Address, and Device ID (see Figure 3.1).

Due to the nature of broadcast UDP packets, CVBrowser has following characteristics:

- ❑ Broadcast packets are not limited by subnet. Even if the IP address of the converters and the computer running CVBrowser that do not belong to the same subnet, it still works fine.
- ❑ Broadcast packets can not pass routers. CVBrowser can only be used to monitor devices with computer running CVBrowser in the same segment of local area network.



The screenshot shows the CVBrowser V1.14 application window. It has a menu bar with 'File', 'View', and 'Help'. Below the menu bar is a toolbar with several icons. The main area contains a table with the following data:

Device Name	IP Address	Subnet Mask	Gateway IP	MAC	ID Number	Version
E-P232-X	192.168.0.100	255.255.255.0	0.0.0.0	00-01-94-90-0D-7A	00000	0.66

(Figure 3.1)


Remark : CVBrowser is a UDP broadcast, it will be blocked by Firewall of your PC OS ,please turn off the firewall of your PC OS

CVBrowser “View”

☐ View -> Refresh

There are two ways for refreshing the status of existing devices. You may select the item “**View**” to refresh the status of existing devices on LAN. Another is to click the icon as red color remark as below. CVBrowser will send another query to get updated information. (see Figure 3.2).


Note: Always run the “**Refresh**” after any data change.



(Figure 3.2)

☐ File -> Exit Alt+F4

Exit from the program (see Figure 3.3).




(Figure 3.3)

CVBrowser “Modify IP”

☐ Modify IP -> Dialog Frame


To click the device on the existing devices list in the CVBrowser table and then the function bar will be enable. To press second icon of “**Modify IP**” on function bar and a dialog frame table will be shown (see Figure 3.4).



(Figure 3.4)

Assign an IP Address with the same Subnet Mask of your computer, avoiding any IP conflict with other network devices.

When you press “**Confirm**” button, the IP address will be refreshed in 2~3 seconds.



(Figure 3.5)

After click “Confirm” button and then “**Input Password**” request will be pop-up on screen (see Figure 3.5). Please simply press “**Confirm**” button and the new device’s IP will be changed and save in table, if you changed it.




(Figure 3.6)

CVBrowser “Modify MAC”

□ Modify MAC -> Dialog Frame


To click the device on the existing devices list in the CVBrowser table and then the function bar will be enabled. To press Third icon of “**Modify MAC**” on function bar and a dialog frame table will be shown (see Figure 3.7).



(Figure 3.7)

□ Input Password -> Dialog Frame

After click “Confirm” button and then “**Input Password**” request will be pop-up on screen (see Figure 3.8). Please simply press “**Confirm**” button and the new device’s MAC will be changed and save in table, if you changed it.



(Figure 3.8)

Web Browser Configuration

The following topics are covered in this chapter:

- **Serial To Ethernet Converter Setup**
 - **Login Setting**
 - **Login Setting Page Field Description**
 - **Parameter Setting**
 - **Parameter Setting Page Field Description**


Login Setting

In addition to basic IP address and subnet mask, specific device settings can be set through HTTP protocol with popular browsers, e.g. Internet Explorer, Netscape, etc. Setup of the converters is as easy as surfing on WWW, no special software will be required.

Setup converter device is as easy as surfing on WWW; no special software will be required. Popular Browsers, such as IE, or Netscape, can easily do the setup process. In the browser URL field, set the IP address of device directly, to enter the **“Login Setting”** page, please follow the steps below.

- Open your browser. This chapter will use IE as an example.
- In the browser URL field, type the IP address of the converter directly and press ENTER. (The IP address is what you set using the Device Management Utility as CVBrowser.)
- To press fourth icon of **“Web Browser”** on function bar and a **“Login Setting”** Screen will be shown (see Figure 3.9) to login into the device.

Alternatively, if the IP address of the converter is already known, you can connect to the converter directly by providing its IP address in the URL field of browsers.



(Figure 3.9)

Login Setting Page Field Description

❑ System time elapsed

The time elapsed since start of this device in [Day Hour : Minute : Second] format. This information can be useful in identifying the reliability of system.

❑ Firmware version

Converter firmware is identified by date code. This information will be required looking for technical support.

❑ Serial number

It is a product serial number code in the converter device and has been provided by factory.

❑ Ethernet MAC Address

Converter is a unique MAC (Media Access Control) address used by Ethernet.

□ **Password**

This field is the administration password for authentication. Factory default is **“empty”**. However, it is not recommended to leave it empty in field operation. If you could not login, it means you have to key in the password. If you do not know the password you can turn off the power and then use any point tip to push **“Reset”** button and hold it to turn on the power at the same time for **5 seconds**. The password will be reset to the factory default as **“empty”**.

Converter device uses the same password protection mechanism commonly used in Windows NT or UNIX. If there are more than **“3 consecutive failures”** in password check during login, the login function will be disabled for **“15 minutes”**. During this 15 minutes period, even if you supply correct password, login will not proceed. This prevents intruders from finding the password by computer generated program.

Parameter Setting Page

□ The Parameter Setting Page

Type the correct password in the **“Password”** field and click the **“Confirm”** button in the **“Login Setting”** page, then the **“Parameter Setting”** page will be shown (see Figure 3.10).

Note: If you forget the password or can't login successfully, please contact the manufacturer directly.

IP address	192.168.0.100
Subnet mask	255.255.255.0
Gateway IP	192.168.0.1
DHCP Client	Disable
Auto Reset (No data input)	0 (Hours)
Device Name	E-P232X-T21
Login password	
Serial I/O Port 1 0	
Local port,Socket mode	100 TCP Server
Remote IP,Port (TCP Client/UDP)	0.0.0.0 0
Interface	RS232
Baudrate	115200
Parity,Data bit,Stop bit	None 8 1
Force off-line time (No data input)	10 (Minute)
Packet collect time	Tx 0 Rx 0 (mSec)
Serial I/O Port 2 0	
Local port,Socket mode	101 TCP Server
Remote IP,Port (TCP Client/UDP)	0.0.0.0 0
Interface	RS422
Baudrate	115200
Parity,Data bit,Stop bit	None 8 1
Force off-line time (No data input)	10 (Minute)
Packet collect time	Tx 0 Rx 0 (mSec)
Digital I/O Port 1 0	
Local port,Socket mode	102 TCP Server
Remote IP,Port (TCP Client/UDP)	0.0.0.0 0
I/O Direction(1 ~ 8)	00000000 (0:Output, 1:Input)
I/O Data(1 ~ 8)	10000000
Force off-line time (No data input)	10 (Minute)
Digital I/O Port 2 0	
Local port,Socket mode	103 TCP Server
Remote IP,Port (TCP Client/UDP)	0.0.0.0 0
I/O Direction(1 ~ 8)	11111111 (0:Output, 1:Input)
I/O Data(1 ~ 8)	00000000
Force off-line time (No data input)	10 (Minute)
Update	

(Figure 3.10)

□ **Parameter Setting Page Field Description**

□ **IP Address**

The IP address of converter device, 4 digits separated by '.' Don't let it conflict with the other devices on the network.

If DHCP client mode is enabled and there's a DHCP server on the network, this field will be assigned by DHCP server automatically.

□ **Subnet mask**

Subnet mask of the converter device has connected to. "255.255.255.0" is usually used for small network, "255.255.0.0" for larger network, 4 digits separated by '.'

If your IP address is provided by an ISP or the internal network administrator, please inquire of them that information and type it correctly.

If DHCP client mode is enabled and there's a DHCP server on the network, this field will be assigned by DHCP server automatically.

□ **Gateway address**

Gateway or Router IP address. 'Gateway' is a device which connects local network to external network. If you need to communicate with other networks or your device owns a real IP address on the internet, please inquire of them that information and type it correctly. If there's no gateway on the network, just leave it as "0.0.0.0".

If DHCP client mode is enabled and there's a DHCP server on the network, this field will be assigned by DHCP server automatically.

□ **DHCP client**

DHCP client mode could be enabled/disabled statues. If DHCP is enabled, there should be a DHCP server on the network. If DHCP is disabled, [IP address], [Subnet mask], and Gateway address] should be manually assigned.

□ **Auto Reset**

It is for resetting when the device has been disconnected or some reasons, the data stop transmitting for a while. You can prevent it and restart the device after waiting a while (1~99 hours) as your settings.

❑ **Device Name**

You can name the device for your operation easily

The total length is 16 digitals .

❑ **Login Password**

For security and management issues, you may setup the “Login Password”. This administration password uses to login converter parameter setting pages. It may be empty or up to 15 characters long.

❑ **Serial I/O Port 1 (RS-232)**

This converter device model provides one serial port as RS-232 interface for connecting the extension serial device.

❑ **Local Port/Socket Mode/Remote IP & Port**

This converter device provides one socket connections port.

❑ **Port number**

A socket port assigned for the serial port. It's a 16-bit numbers, ranging from 1 to 65535. Because the numbers below 1000 are used for specific purposes (e.g. 80 is for HTTP protocol), we suggest you use the numbers larger than **1000**. Generally the port number 4660 is used for the serial communication. However you should specify different port number for each serial port.

❑ **Socket type**

- ❑ TCP Server: TCP protocol, passive open, to be connected from the TCP client.
- ❑ TCP Client: TCP protocol, active open, connect to the TCP server
- ❑ UDP: UDP protocol, connectionless

❑ **Remote IP address**

The server IP address and socket port would be connected in TCP Server, TCP Client and UDP mode for a certain serial port.

❑ **Remote socket port**

The server socket port would be connected in TCP Client and UDP mode for a certain serial port.

❑ **Interface of serial I/O**

RS-232❑TxD, RxD for data stream, no flow control

RS-232 (RTS/CTS)❑TxD, RxD for data stream, RTS/CTS for flow control.

❑ **Baudrate**

Baud Rate: 300 ~ 115.2K bps

❑ **Parity, Data bits, Stop bit**

Parity: None, Even, Odd, Space, Mark.

Data Bits: 5, 6, 7, 8.

Stop Bit: 1 or 2.

❑ **Force off-line time**

It is for setting the off-line time period of device will be taken when there is no data input. The parameter can be from “0 to 99” and the time unit is “Minute”.

❑ **Packet Collect Time**

It is for setting a packet collecting period of the device serial port's Tx and Rx. The parameter can be from “0 to 999” and the time unit is “mSec”.

❑ **Serial I/O Port 2 (RS-232/422/485)**

This converter device model is provided second serial port as RS-232/422/485 (Auto-Detect) interfaces for connecting the extension serial device.

❑ **Local Port/Socket Mode/Remote IP & Port**

This converter device provides 1 socket connection port.

❑ **Port number**

A socket port is assigned for the serial port. It's a 16-bit numbers, ranging from 1 to 65535. Because the numbers below 1000 are used for specific purposes (e.g. 80 is for HTTP protocol), we suggest you use the numbers larger than **1000**. Generally the port number 4660 is used for the serial communication. However you should specify different port number for each serial port.

❑ **Socket type**

- ❑ TCP Server: TCP protocol, passive open, to be connected from the TCP client.
- ❑ TCP Client: TCP protocol, active open, connects to the TCP server.
- ❑ UDP : UDP protocol, connectionless

❑ **Remote IP address**

The server IP address and socket port would be connected in TCP Client and UDP mode for a certain serial port.

❑ **Remote socket port**

The server socket port would be connected in TCP Server, TCP Client and UDP mode for a certain serial port.

❑ **Interface of serial I/O**

It provides an “**Auto Detect**” function and just depends on the connected serial device’s interface as RS-232, RS-422 or RS-485.

❑ **Baudrate**

Baud Rate: 300 ~ 115200 bps

❑ **Parity, Data bits, Stop bit**

Parity: None, Even, Odd, Space, Mark.

Data Bits: 5, 6, 7, 8.

Stop Bit: 1 or 2.

❑ **Force off-line time**

It is for setting the off-line time period of device will be taken when there is no data input. The parameter can be from “**0 to 99**” and the time unit is “**Minute**”.

❑ **Packet Collect Time**

It is for setting a packet collecting period of the device serial port’s Tx and Rx. The parameter can be from “**0 to 999**” and the time unit is “**mSec**”.

❑ **Interface of serial I/O**

- ❑ RS-232: TxD, RxD for data stream, no flow control
- ❑ RS-232 (RTS/CTS): TxD, RxD for data stream, RTS/CTS for flow control
- ❑ RS-485 (Half-duplex): Half-duplex RS-485 interface
- ❑ RS-422 (Full-duplex): Full-duplex RS-422 interface

Controller Updated

Press “Update” Button after finish the detailed parameter setting. The converter will save all parameters into internal non-volatile memory and then reboot (see Figure 5.3). It takes about 5 seconds to complete the whole process, and a new login page will be presented (see Figure 5.1).



(Figure 5.3)

You can re-login and check if all parameters have been correctly saved. If everything is ok, you can close the browser now.

Note : If the domain of the converter is different from that of the computer running the browser, the login page won't appear unless the converter's "Gateway Address" has been correctly set.

Factory Default Setting

If you forget the setup password or have incorrect settings making the converter inoperable, there are two ways to reset the setting and the following procedures can be used to reset all settings to factory default:

A:

1. Please turn on the power and then use any point tip to push “Reset” button for 3 seconds. The password will be reset to the factory default as “empty”.

Setting Verification

After complete the wiring and parameter setting, we should verify if the setting is correct. This chapter will introduce how to use a single computer to test if the converter behaves well.

The operating system can be Windows 95, 98, ME, XP, 2000, Vista, Win-7. The “Hyper Terminal” utility should be installed on your PC (see Figure 6.1). It can be found in your Windows installation CD.

The wiring architecture is similar to “RS-232 Wiring” in chapter 3, and the “Serial Device” is replaced by the PC’s COM 1. The same PC also plays the roll of the Remote Host.

The following topics are covered in this chapter:


- ❑ **Hyper Terminal for TCP/IP WinSock**
- ❑ **Hyper Terminal for COM Port**
- ❑ **Data Transmission**

Hyper Terminal for TCP/IP WinSock

Initiate a Hyper Terminal from the Start Menu in Windows (see Figure 6.1), give a terminal name, choose an icon, and press “OK” button (see Figure 6.2).




(Figure 6.1)




(Figure 6.2)

Select “TCP/IP (Winsock)” option at the “Connect using:” field (see Figure 6.3).




(Figure 6.3)

After “OK” button is pressed, Figure 6.4 appears. Enter the converter’s IP address (e.g. 192.168.123.10) at the “Host address:” field, and the Socket port number set for the Serial Port 1 at the “Port number:” field (e.g 4660). (The Socket type of the Serial Port 1 should be “TCP Server”.)



(Figure 6.4)


After “OK” button is pressed, Figure 6.5 appears. If the Hyper Terminal connects with the converter successfully, the time clock at the left lower corner “Connected hh:mm:ss” will start counting.



(Figure 6.5)

Hyper Terminal for COM Port

Initiate another Hyper Terminal as a COM Port Terminal (in Figure 6.3, select COM 1 or other COM port instead of “TCP/IP (Winsock)”). Set the COM port Properties to be the same as those set for the Serial Port 1 of the converter.



(Figure 6.3)

Data Transmission

When all steps described above are finished, type any texts on the COM Port Terminal and check if the texts are also displayed on the TCP/IP Winsock Terminal. Alternatively, check if the characters typed on the TCP/IP Winsock Terminal are also displayed on the COM Port Terminal. If yes, then all settings are correct and the converter can operate properly.

Appendix A

FAQ

Q. Why can't the CVBrowser.exe detect the converter on the network?

A. Please check

- ☐ if the power is properly plugged to the converter.
- ☐ if the network cable is properly connected between the converter and the Hub.

Please refer to the “Hardware Installation” steps in Chapter 3.



Q. Why can't I use IE to setup the converter?

A. Please check if the network domain of your PC is the same as that of the converter.

Appendix B

Pin outs and Cable Wiring


□ DC In Jack



□ RJ-45 Pin Assignment


RJ45 Port

Pin	Signal
1	Tx+
2	Tx-
3	Rx+
6	Rx-



□ RS-232 Pin Assignment

The pin assignment scheme for a 9-pin male connector on a DTE is given below.



PIN 1 : N/A

PIN 2 : RXD

PIN 3 : TXD

PIN 4 : DTR

PIN 5 : GND

PIN 6 : DSR

PIN 7 : RTS

PIN 8 : CTS

PIN 9 : N/A

□ RS-232 Wiring Diagram


Serial Device

EDIO-232 Converter

2	RX	3	TX
3	TX	2	RX
5	GND	5	GND
7	RTS	8	CTS
8	CTS	7	RTS

❑ RS-422 Pin Assignment

The pin assignment scheme for a 4-pin RS-422 is given below.



PIN 1 : R-

PIN 2 : R+

PIN 3 : T-

PIN 4 : T+

❑ RS-422 Wiring Diagram

Serial Device

E-232-X-DIO Converter

R-	3	T-
R+	4	T+
T-	1	R-
T+	2	R+

❑ RS-485 Wiring Diagram

Serial Device

EDIO-232 Converter

D+	D-
D-	D-